Step 1 : **Connect To Computer**

A) Unplug power supply from pedal.

B) Connect micro-USB cable from computer to pedal.

Step 2 : **Open NUX DFU Updater**

A) Click on: NUX DFU Updater

Open Window



B) Hold down pedal footswitch & Plug in the power receptor.

You Will See



Step 3 : **Select Pedal Bin**




NUX Firmware Updater v1
YOUR PEDAL NAME
Product:V1
Version:2.0.0
V2.0
1.Support Tape Core Editor
2.Add new reverb effect (need TapeCore Editor)
3.Add Smart Tap Tempo Mode (need TapeCore Editor)
4.Add Sync Mode (need TapeCore Editor)
2.Let Device into DFU mode and connect To Computer.
Ensure the firmware is match the device.
Start Update
Select File...
v1.1.2

A) Click on: **Select File**

B) Select bin file (zip)

Step 4 : **Start Updating**


NUX Firmware Updater v1
YOUR PEDAL NAME
Product: Monterey Vibe
Version: MR01M1.1
v1.1
1.Adds new vibrato mode.
Usage: Press and hold foot switch for 2 seconds to switch effects between chorus and vibrato.
RED LED: Chorus mode
GREEN LED: Vibrato mode
2.Adds smart tao tempo
Usage: tap the foot switch to the beat(quarter-note tempo), the speed of effect will change to the interval between the last two taps. The two taps must be less than 1.5 seconds apart(greater than 40 BPM).
3.Device found. Click update and continue.
Start Update
Select File...
v1.1.2

Start Update

Light Will Flash

(During & After Update Complete)

Step 5 : **Let File Install**

Do Not Unplug Pedal !

When Update is Complete Will Say


NUX Firmware Updater v1
YOUR PEDAL NAME
Product: Monterey Vibe
Version: MR01M1.1
v1.1
1.Adds new vibrato mode.
Usage: Press and hold foot switch for 2 seconds to switch effects between chorus and vibrato.
RED LED: Chorus mode
GREEN LED: Vibrato mode
2.Adds smart tao tempo
Usage: tap the foot switch to the beat(quarter-note tempo), the speed of effect will change to the interval between the last two taps. The two taps must be less than 1.5 seconds apart(greater than 40 BPM).
4. Update Finished.
Start Update
Select File...
v1.1.2

Step 6 : **Finishing Update**

A) Close the update window


NUX Firmware Updater v1
YOUR PEDAL NAME
Product: Monterey Vibe
Version: MR01M1.1
v1.1
1.Adds new vibrato mode.
Usage: Press and hold foot switch for 2 seconds to switch effects between chorus and vibrato.
RED LED: Chorus mode
GREEN LED: Vibrato mode
2.Adds smart tao tempo
Usage: tap the foot switch to the beat(quarter-note tempo), the speed of effect will change to the interval between the last two taps. The two taps must be less than 1.5 seconds apart(greater than 40 BPM).
4. Update Finished.
Start Update
Select File...
v1.1.2

B) Unplug power & micro-USB from pedal



C) Enjoy the pedal !